OUTDECO

Care and maintenance

How to care for OUTDECO Weathertex-based decorative screen panels and their finish.

Routine care

Inspect panels, fixings, joints and supporting frames periodically. Remove loose dirt with a soft brush and clean gently with water and a mild product suitable for exterior timber. Do not use aggressive cleaning methods that may damage the surface.

Natural weathering

Natural Brown gradually softens and lightens with sunlight and weather. Fully exposed panels generally change more evenly than shaded panels. Colour change, natural variation and tannin release are not necessarily material defects.

Recoating

Clean the panels and allow them to dry before recoating. Use a compatible exterior water-based paint or pigmented timber stain, test a concealed area first and follow the coating manufacturer’s directions.

Keep water moving

Maintain ground clearance and drainage. Do not allow soil, mulch, standing water or constant moisture to remain in contact with the panels.

Repairs and advice

Replace damaged or corroded fixings with suitable exterior-grade fasteners. Contact OUTDECO before making warranty-related alterations or disposing of a panel that may be subject to a claim.